GstarCAD vs AutoCAD® | COMPARISON

COMPARE THE GSTARCAD 2024 WITH AUTOCAD® 2024 AND AUTOCAD® LT 2024.

REMARKS

This table is for reference only.

Empty space means functionally not supported.

The package that contains LT version does not support BEDIT.

Table comparison updated on Aug 1st, 2023

| FILES | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
|---|--------------------------|----------------------|-----------|----------------|
| Purge | ✓ | ✓ | ✓ | ✓ |
| Etransmit | √ | √ | ✓ | ✓ |
| Sheet Set Manager | ✓ | √ | ✓ | √ |
| CAD Standard .dws | ✓ | ✓ | ✓ | |
| DWF Underlay | √ | ✓ | ✓ | √ |
| PDF Underlay | ✓ | ✓ | ✓ | √ |
| DGN Import and Underlay | ✓ | √ | ✓ | √ |
| DWG Convert | ✓ | √ | ✓ | ✓ |
| Import to WMF, SAT, 3DS, DWF, DWFX, DGN, PDF | ✓ | √ | ✓ | √ |
| Export to DWG, DWF, DWFX, WMF, EMF. SAT, STL, EPS, DXX, BMP,SVG | √ | ✓ | √ | ✓ |
| Plot and Publish to PDF | ✓ | √ | ✓ | ✓ |
| Publish to DWF 2D & 3D | ✓ | √ | ✓ | √ |
| Collaboration | √ | ✓ | Different | Different |
| IFC format | √ | ✓ | | |
| Single-document Mode | √ | ✓ | √ | ✓ |

| Digital Signature | ✓ | ✓ | ✓ | ✓ |
|---|--------------------------|----------------------|----------|-------------|
| Batch Digital Signing Tool | ✓ | ✓ | √ | √ |
| Reset Settings to Default. | ✓ | ✓ | ✓ | ✓ |
| DWF Import | ✓ | ✓ | | |
| Mark Up | | | ✓ | ✓ |
| STEP / IGES Files | √ | | √ | |
| | | | | |
| INTERFACE | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| Quick Properties | ✓ | ✓ | ✓ | ✓ |
| Block Palette | | | ✓ | ✓ |
| Dark Theme | ✓ | ✓ | ✓ | ✓ |
| Hidden Message Settings | ✓ | ✓ | ✓ | ✓ |
| WorkSpace command | ✓ | ✓ | ✓ | ✓ |
| CUI Menus and Toolbars | ✓ | ✓ | ✓ | |
| CUI Import & Export | ✓ | ✓ | ✓ | ✓ |
| Drag and Drop Customization | ✓ | ✓ | | |
| Visual Menu Customization | √ | ✓ | ✓ | ✓ |
| Ribbon/Classic | √ | ✓ | ✓ | ✓ |
| Properties Palettes | ✓ | ✓ | ✓ | √ |
| Design Center/Tool Palette/Xref Palette | ✓ | √ | ✓ | ✓ |
| Command Line | ✓ | √ | ✓ | √ |
| Clean Screen | √ | ✓ | ✓ | √ |
| Dynamic Input and Auto Complete | ✓ | ✓ | ✓ | ✓ |

| Clickable Command Line Options | | | ✓ | ✓ |
|--|--------------------------|----------------------|----------|-------------|
| File Tab | ✓ | √ | √ | ✓ |
| Floating Windows | | | ✓ | ✓ |
| | | | | |
| | | | | |
| | | | | |
| SELECTION, SNAP & TRACK | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| Navigation Cube | ✓ | ✓ | ✓ | ✓ |
| SELECTIONCYCLING | √ | √ | ✓ | ✓ |
| Right-Click + Drag Method | √ | ✓ | ✓ | ✓ |
| Selection Preview | ✓ | ✓ | ✓ | ✓ |
| Selection Effect Customization | | | ✓ | ✓ |
| Quick Select | ✓ | ✓ | ✓ | ✓ |
| Select Similar | ✓ | ✓ | ✓ | ✓ |
| Multifunctional Grips | ✓ | √ | ✓ | ✓ |
| Osnap | ✓ | ✓ | ✓ | ✓ |
| Grid and Snap | ✓ | ✓ | ✓ | ✓ |
| Polar Track | ✓ | ✓ | ✓ | ✓ |
| Distance from Endpoint and Divide Segments | ✓ | ✓ | | |
| Group | ✓ | ✓ | ✓ | ✓ |
| ADDSELECTED command | ✓ | ✓ | ✓ | √ |
| Multiple command | ✓ | ✓ | ✓ | ✓ |
| | | | | |

| DIMENSIONS | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
|----------------------------------|--------------------------|----------------------|------------|-------------|
| DIMCENTER Command | ✓ | ✓ | Partially | Partially |
| Reassociate Dimension | √ | ✓ | ✓ | ✓ |
| DIMTOFFSET | ✓ | ✓ | | |
| Quick Measure | Rapid Distance | Rapid Distance | ✓ | ✓ |
| Standard Dimensions | √ | ✓ | ✓ | ✓ |
| Associative Dimension | √ | √ | ✓ | ✓ |
| Quick Dimension | √ | ✓ | ✓ | ✓ |
| Qleader | √ | ✓ | ✓ | ✓ |
| Dimension Break | ✓ | √ | ✓ | ✓ |
| Multileaders | ✓ | √ | ✓ | ✓ |
| Smart Dimensioning | | | ✓ | ✓ |
| Dynamic Dimensioning | ✓ | ✓ | ✓ | ✓ |
| TEXT | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| Text Align / Text Match | √ | ✓ | Text Align | Text Align |
| Change Text | √ | ✓ | | |
| Mtext | ✓ | ✓ | ✓ | ✓ |
| Mtext Superscript and Subscripts | ✓ | ✓ | ✓ | ✓ |
| Text | √ | ✓ | √ | ✓ |
| Multi-language Character Set | √ | √ | ✓ | ✓ |
| In-place Text Editor | √ | √ | ✓ | ✓ |
| Mtext Editor | √ | √ | ✓ | ✓ |
| Support .shx and .ttf font | √ | ✓ | √ | ✓ |

| Spelling | ✓ | ✓ | ✓ | ✓ |
|--------------------------------|--------------------------|----------------------|----------|-------------|
| Check spelling in Mtext | ✓ | ✓ | ✓ | ✓ |
| Field | ✓ | ✓ | ✓ | ✓ |
| Revcloud | ✓ | ✓ | ✓ | ✓ |
| Wipeout Circle and Arc Options | ✓ | ✓ | | |
| Text Incremental Copy | ✓ | ✓ | | |
| Automatic Text Numbering | ✓ | ✓ | ✓ | √ |
| Text on line | ✓ | ✓ | | |
| Statistics Summation | ✓ | ✓ | | |
| LAYERS | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| Auto Layer | ✓ | ✓ | | |
| Change to ByLayer (SETBYLAYER) | ✓ | ✓ | ✓ | ✓ |
| Layer Properties Manager | ✓ | ✓ | ✓ | ✓ |
| Layer States Manager | ✓ | ✓ | ✓ | ✓ |
| Layer Translator | ✓ | ✓ | ✓ | |
| Layer Walk | ✓ | ✓ | ✓ | ✓ |
| Layer Previous | ✓ | ✓ | ✓ | ✓ |
| Layer Isolate | ✓ | ✓ | ✓ | ✓ |
| Layer Unisolate | ✓ | ✓ | ✓ | ✓ |
| Layer Lock | ✓ | ✓ | ✓ | ✓ |
| Layer Unlock | ✓ | ✓ | ✓ | ✓ |
| Layer Unlock All | ✓ | ✓ | | |
| Lock Other Layers | ✓ | √ | | |

| Layer Freeze | √ | ✓ | √ | √ |
|---|--------------------------|----------------------|----------|-------------|
| | | | | , |
| Freeze Other Layer | √ | √ | | |
| Thaw All Layers | ✓ | ✓ | ✓ | √ |
| Layer Off | √ | ✓ | ✓ | ✓ |
| Off Other Layer | ✓ | ✓ | | |
| Turn All Layers On | ✓ | ✓ | √ | ✓ |
| Layer Merge | √ | √ | ✓ | ✓ |
| Layer Delete | √ | √ | ✓ | ✓ |
| Layer Match | ✓ | √ | ✓ | √ |
| Viewport Layer | √ | √ | √ | ✓ |
| НАТСН | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| Hatch objects from Tool Palettes | ✓ | ✓ | ✓ | ✓ |
| Gradient Hatches | ✓ | ✓ | ✓ | ✓ |
| Custom Patterns | ✓ | √ | ✓ | √ |
| Background and Color for Hatch Patterns | ✓ | √ | ✓ | ✓ |
| Trim/Extend of/to Hatch Pattern Entities | ✓ | √ | ✓ | √ |
| Superhatch | ✓ | √ | √ | |
| Transparency for Hatch | √ | √ | ✓ | ✓ |
| Trim/Extend/Hatch preview | ✓ | √ | √ | √ |
| RASTER IMAGES | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| Raster Image Support (Clipping, Transparency,) | ✓ | ✓ | ✓ | ✓ |
| Support Kinds of Image Files (bmp\jpg\png\tga\tif\gif\pcx\ecw\) | √ | ✓ | √ | ✓ |
| EXPRESS TOOLS | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |

| Lockup Command | ✓ | ✓ | | |
|-------------------------------------|----------|----------|------------------|------------------|
| Layout Merge | ✓ | ✓ | ✓ | ✓ |
| Synchronize Viewports | √ | ✓ | ✓ | √ |
| Breakpoint Check (CLOSELINE) | ✓ | ✓ | | |
| Fast Select (FASTSEL) | ✓ | ✓ | ✓ | ✓ |
| Change Base | √ | ✓ | | |
| Layer Draw Order | ✓ | ✓ | | |
| Stat, Blocks Number | ✓ | √ | Count Command | Count Command |
| Area Table | √ | ✓ | | |
| Break Object | √ | ✓ | | |
| Block Break | √ | ✓ | | |
| Graphic Compare | ✓ | ✓ | | |
| Batpurge | √ | ✓ | | |
| Layout by Path | √ | ✓ | Array path | Array path |
| Line2pl | ✓ | ✓ | | |
| Sptpl | ✓ | ✓ | | |
| GstarCAD Tools | √ | ✓ | | |
| Plot tools | ✓ | ✓ | | |
| Drawing Compare | ✓ | √ | DWG COMPARE | DWG COMPARE |
| Delete Duplicate Objects (OVERKILL) | √ | ✓ | ✓ | ✓ |
| Block Replace | ✓ | √ | ✓ | ✓ |
| | | | | |

| OTHERS | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
|---|--------------------------|----------------------|----------|-------------|
| Region | ✓ | | ✓ | ✓ |
| Make Shape | ✓ | ✓ | ✓ | ✓ |
| Import Layout as Sheet | ✓ | ✓ | ✓ | ✓ |
| Viewport Scale | ✓ | √ | ✓ | ✓ |
| VPMAX / VPMIN | ✓ | ✓ | ✓ | ✓ |
| Attribute Increment | ✓ | √ | | |
| Define Layout Viewport from ModelSpace (M2LVPORT) | √ | √ | | |
| Security | ✓ | ✓ | ✓ | |
| Free Scale | ✓ | ✓ | | |
| Hatch to Back | ✓ | ✓ | ✓ | ✓ |
| Reverse | ✓ | √ | ✓ | ✓ |
| Synchronize Attributes | ✓ | √ | ✓ | ✓ |
| Clip | ✓ | ✓ | ✓ | ✓ |
| Array Options | ✓ | √ | ✓ | ✓ |
| Align Tool / Arrange Tool | ✓ | ✓ | | |
| Areasum | ✓ | ✓ | | |
| Table | ✓ | √ | ✓ | ✓ |
| Symmetric Draw | ✓ | ✓ | | |
| Outline Objects | ✓ | ✓ | | |
| Smart centerlines/center marks | | | ✓ | ✓ |
| Invert Fillet | ✓ | ✓ | | |
| Draw and Modify Commands | ✓ | ✓ | √ | ✓ |

| Offset Multiple | √ | ✓ | ✓ | ✓ |
|---------------------------------------|----------|-----------|----------|---|
| Helix | √ | ✓ | ✓ | ✓ |
| Real Time Pan & Zoom | √ | ✓ | ✓ | ✓ |
| SteeringWheels | | | ✓ | ✓ |
| Redraw and Regeneration | ✓ | ✓ | ✓ | ✓ |
| Layout and Paper Space | ✓ | ✓ | ✓ | ✓ |
| Layout Viewport settings | ✓ | ✓ | ✓ | ✓ |
| Magnifier | ✓ | | | |
| Barcode & QR Code | ✓ | ✓ | | |
| Non-rectangular Viewports | ✓ | ✓ | ✓ | ✓ |
| Shortcut Customization (CUSTACC) | ✓ | ✓ | | |
| Match Properties Across Drawings | ✓ | ✓ | ✓ | ✓ |
| Multilines and Multiline Styles | ✓ | ✓ | √ | |
| Block Create and Insert | ✓ | ✓ | √ | ✓ |
| Redefine Block | ✓ | ✓ | ✓ | ✓ |
| Block Attribute Definition | ✓ | ✓ | ✓ | ✓ |
| Refedit | ✓ | ✓ | ✓ | ✓ |
| Hyperlink | ✓ | ✓ | ✓ | ✓ |
| Scale List | ✓ | ✓ | ✓ | ✓ |
| Dynamic Block Creat/ Insert/View/Edit | ✓ | Partially | ✓ | ✓ |
| Table Tools | ✓ | ✓ | | |
| AutoXLSTable | √ | ✓ | | |
| Pline Boolean | √ | ✓ | | |

| Xref path repair | | | ✓ | ✓ |
|-----------------------------|--------------------------|----------------------|----------|-------------|
| Undo/Redo Preview | ✓ | ✓ | ✓ | ✓ |
| 3D | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| POLYSOLID | ✓ | | ✓ | |
| PLANESURF | ✓ | | ✓ | |
| SURFOFFSET | ✓ | | ✓ | |
| CONVTOMESH | ✓ | | ✓ | |
| CONVTOSOLID | ✓ | | ✓ | |
| CONVTOSURFACE | ✓ | | ✓ | |
| CONVTONURBS | ✓ | | ✓ | |
| Point Cloud | ✓ | ✓ | ✓ | |
| 3D Edition Grips | ✓ | | ✓ | |
| Section Plane | ✓ | | ✓ | |
| Flatshot | ✓ | | ✓ | |
| 3D Surfaces | ✓ | ✓ | ✓ | |
| ACIS Modeling & Editing | ✓ | | ✓ | |
| 3D Orbit options | √ | ✓ | ✓ | |
| Camera | | | ✓ | |
| Render | √ | | ✓ | |
| Visual Styles Manager | √ | | ✓ | |
| Solid editing | ✓ | | ✓ | |
| Solprof / Solview / Soldraw | ✓ | | ✓ | |
| | | | | |

| PRINTING | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
|------------------------------------|--------------------------|----------------------|----------|-------------|
| CTB & STB Plot Style Files | √ | ✓ | ✓ | √ |
| Plot Styles Table Editor | √ | ✓ | ✓ | ✓ |
| Built-in Print Driver | √ | √ | ✓ | ✓ |
| Import & Editing of Page Setups | √ | √ | √ | ✓ |
| Publish | √ | ✓ | ✓ | ✓ |
| Viewport Max | | | ✓ | ✓ |
| 3D Print Studio | | | ✓ | |
| Hide and Shade Plot | √ | ✓ | ✓ | ✓ |
| Batch Print | √ | √ | | |
| Arrange frame | ✓ | √ | | |
| PROGRAMMING | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| LISP Debugger | ✓ | √ | √ | ✓ |
| Entity Data Editor | √ | √ | ✓ | |
| Action Recording and Action Macros | | | ✓ | |
| LISP vl-, vlr-, vla- and vlax | √ | ✓ | ✓ | |
| LISP Encryption | √ | √ | ✓ | |
| (SDS/ADS) | √ | √ | ✓ | |
| DCL / DCL engine / COM API | √ | √ | ✓ | |
| Visual Basic for Applications | ✓ | ✓ | ✓ | |
| VBA VBI Projects Support | ✓ | √ | DVB | |
| .Net Framework | √ | ✓ | ✓ | |
| GRX (GstarCAD Runtime eXtension) | ✓ | ✓ | ARX | |

| CUI Menu Support/Diesel Expressions | √ | ✓ | ✓ | ✓ |
|--|--------------------------|----------------------|----------------|----------------|
| Diesel Expressions | √ | ✓ | ✓ | ✓ |
| MNU and MNS File Support | √ | ✓ | ✓ | ✓ |
| API (Toolbar & Menu Customization) | √ | ✓ | ✓ | |
| LICENSING OPTIONS | GSTARCAD PROFESSIONAL | GSTARCAD STANDARD | AUTOCAD® | AUTOCAD® LT |
| Perpetual / Stand-alone / Online Activate | ✓ | ✓ | | |
| Perpetual / Network / Online Activate | ✓ | ✓ | | |
| Perpetual / Stand-alone / USB Dongle | ✓ | ✓ | | |
| Perpetual / Network / USB Dongle | ✓ | ✓ | | |
| Subscription / Stand-alone / Online Activate | ✓ | ✓ | √ (named user) | √ (named user) |
| Subscription / Network / Online Activate | ✓ | ✓ | | |